

# EASISOLV 601

## SCREEN WASH AND STAIN REMOVER

EasiSolv 601 Screen Wash & Stain Remover is designed to dissolve all types of ink from the screen printing mesh before removing the emulsion. This product is applied to the screen printing mesh and rinsed with water. It also contains surfactants that degrease the screen printing mesh when used as a final step in the reclaiming process.

<b>Appearance:</b>	Clear, slight yellow
<b>Odor:</b>	Mild Floral
<b>Ph:</b>	Not Determined
<b>Flash Point:</b>	91°C / 196°F
<b>Specific Gravity:</b>	1.003 g/cc @ 20°C/68°F
<b>Weight/gl:</b>	Not Determined
<b>VOCs:</b>	Not Determined
<b>Dot Shipping:</b>	Non-hazardous

<b>Quart</b>	
<b>Gallon</b>	601-1 GL
<b>5 Gallon pail</b>	601-5 GL
<b>55 Gallon Drum</b>	601-55 GL

### STORAGE REQUIREMENTS

Keep the container tightly closed. Store in a dry, cool and well ventilated place away from incompatible materials such as oxidizing agents.

### PRODUCT FEATURES

- Best stain remover for waterbased inks
- Doesn't foam
- Contains degreasers
- Non-hazardous
- Non-caustic
- Good for HSA/Discharge stains

### APPLICATION/USE

Scrape excess ink from the screen, apply EasiSolv 601 to the ink side and print side of the screen and scrub. Using a good high pressure washer, spray rinse the screen starting at the bottom on the ink side and work up. Give good attention to the image area. Rinse the print side of the screen. Apply an Easiway emulsion remover. If stubborn stains remain, apply EasiSolv 601 as a stain remover.

### COMPATIBLE INK TYPES

- Plastisol
- Waterbased
- UV/Solvent
- Silicone
- Industrial